

# SXP9050 User Manual

**SINOX**

## Specifications

- Product model: Sinox MagSafe® mobile powerbank
- Capacity: 5000mAh
- Input: Type-C™ 5V/3A, 9V/2A
- Output (max): Type-C™ 20W
- Output wireless (max): 5W, 7.5W, 10W, 15W
- Battery type: Polymer lithium ion
- Dimension: 120\*63\*10mm
- Product material: PC + Aluminum

## Instructions

1. When charging the powerbank, first connect the power cord with the powerbank Type-C™, and then connect the other end with the wall charger.
2. The LED1,2,3,4 lights show remaining power. When charging the powerbank the LED light will flash. LED5 lights up when Type-C port under QC or PD quick charging mode.
3. If the phone cover does not have built-in magsafe, the included metal ring can be placed on the inside of the cover to make it magnetic.
4. Turn on the powerbank by pushing the button. Point the powerbank at the wireless charging receiving position of the mobile phone to charge the mobile phone.
5. Remove the powerbank from the mobile phone to stop charging.
6. The powerbank switches off automatically if it is not in use.
7. If the Qi wireless receiving equipment is too far away from the center of the powerbank, the device will not enter charging mode. Please adjust the device to the center of the powerbank, and the device will automatically go into charging mode.
8. In case of charging failure, remove the mobile phone from the powerbank, then put it back on for the phone to enter charging mode again.

## Attention

1. The power bank has overcurrent protection (OCP), short circuit protection, overvoltage and undervoltage protection (UVP), foreign object (FOD), no-load protection and other functions.
2. Avoid direct sunlight, high temperature, and stay away from fire and other heat sources.
3. Store in dry environment and avoid corrosive substances.
4. The powerbank must be kept at 50% of the rated capacity if not used for more than 3 months.
5. To prevent explosion, avoid exposing the powerbank to fire. Do not disassemble.

**Sinox Europe A/S**  
Troensevej 11. DK-9220 Aalborg

# SXP9050 Brugervejledning SINOX

## Specifikationer

- Produktmodel: Sinox MagSafe® mobil powerbank
- Kapacitet: 5000mAh
- Input: Type-C™ 5V/3A, 9V/2A
- Output (max): Type-C™ 20W
- Output trådløs (max): 5W, 7.5W, 10W, 15W
- Batteri type: Polymer lithium ion
- Dimensioner: 120\*63\*10mm
- Produkt materiale: PC + Aluminum

## Instruktioner

1. Når du oplader powerbanken, skal du først forbinde ledningen med powerbankens Type-C™, og derefter forbinde den anden ende med opladeren.
2. LED1,2,3,4 lys viser tilbageværende strøm. Ved opladning af powerbanken blinker LED-lyset. LED5 lyser, når Type-C porten benyttes under QC eller PD hurtigopladningsmode.
3. Hvis ikke telefonens cover er med indbygget magsafe, kan den medfølgende metalring placeres på indersiden af coveret for at gøre det magnetisk.
4. Tænd powerbanken på knappen og ret powerbanken mod den trådløse opladningsposition på mobiltelefonen for at oplade mobiltelefonen.
5. Fjern powerbanken fra mobiltelefonen for at stoppe opladningen.
6. Powerbanken slukker automatisk, hvis ikke den bliver benyttet.
7. Hvis det trådløse Qi-udstyr er langt væk fra midten af powerbanken, vil enheden ikke gå i opladningstilstand. Flyt enheden til midten af powerbanken, og opladningen vil automatisk starte.
8. Ved ladefejlfjern mobiltelefonen fra powerbanken og sæt den på powerbanken for at gå tilbage til opladningstilstand.

## Vigtigt

1. Powerbanken har overstrømsbeskyttelse (OCP), kortslutningsbeskyttelse, overspændings-, underspændingsbeskyttelse (UVP), fremmedlegemer (FOD), dvalebeskyttelse og andre funktioner.
2. Undgå direkte sollys, høje temperaturer, og hold enheden væk fra ild og andre varmekilder.
3. Opbevares i et tørt miljø og undgå ætsende stoffer.
4. Powerbanken skal holdes på 50% af den nominelle kapacitet, hvis den ikke benyttes i mere end 3 måneder.
5. For at forhindre eksplosion, undgå at udsætte powerbanken for ild. Må ikke skilles ad.

**Sinox Europe A/S**  
Troensevej 11. DK-9220 Aalborg

# SXP9100 User Manual

**SINOX**

## Specifications

- Product model: Sinox MagSafe® mobile powerbank
- Capacity: 10000mAh
- Input: Type-C™ 5V/3A, 9V/2A
- Output (max): Type-C™ 20W
- Output wireless (max): 5W, 7.5W, 10W, 15W
- Battery type: Polymer lithium ion
- Dimension: 120\*63\*16mm
- Product material: PC + Aluminum

## Instructions

1. When charging the powerbank, first connect the power cord with the powerbank Type-C™, and then connect the other end with the wall charger.
2. The LED1,2,3,4 lights show remaning power. When charging the powerbank the LED light will flash. LED5 lights up when Type-C port under QC or PD quick charging mode.
3. If the phone cover does not have built-in magsafe, the included metal ring can be placed on the inside of the cover to make it magnetic.
4. Turn on the powerbank by pushing the button. Point the powerbank at the wireless charging receiving position of the mobile phone to charge the mobile phone.
5. Remove the powerbank from the mobile phone to stop charging.
6. The powerbank switches off automatically if it is not in use.
7. If the Qi wireless receiving equipment is too far away from the center of the powerbank, the device will not enter charging mode. Please adjust the device to the center of the powerbank, and the device will automatically go into charging mode.
8. In case of charging failure, remove the mobile phone from the powerbank, then put it back on for the phone to enter charging mode again.

## Attention

1. The power bank has overcurrent protection (OCP), short circuit protection, overvoltage and undervoltage protection (UVP), foreign object (FOD), no-load protection and other functions.
2. Avoid direct sunlight, high temperature, and stay away from fire and other heat sources.
3. Store in dry environment and avoid corrosive substances.
4. The powerbank must be kept at 50% of the rated capacity if not used for more than 3 month.
5. To prevent explosion, avoid exposing the powerbank to fire. Do not disassemble.

Sinox Europe A/S  
Troensevej 11. DK-9220 Aalborg

# SXP9100 Brugervejledning SINOX

## Specifikationer

- Produktmodel: Sinox MagSafe® mobil powerbank
- Kapacitet: 10000mAh
- Input: Type-C™ 5V/3A, 9V/2A
- Output (max): Type-C™ 20W
- Output trådløs (max): 5W, 7.5W, 10W, 15W
- Batteri type: Polymer lithium ion
- Dimensioner: 120\*63\*16mm
- Produkt materiale: PC + Aluminum

## Instruktioner

1. Når du oplader powerbanken, skal du først forbinde ledningen med powerbankens Type-C™, og derefter forbinde den anden ende med opladeren.
2. LED1,2,3,4 lys viser tilbageværende strøm. Ved opladning af powerbanken blinker LED-lyset. LED5 lyser, når type C porten benyttes under QC eller PD hurtigopladningsmode.
3. Hvis ikke telefonens cover er med indbygget magsafe, kan den medfølgende metalring placeres på indersiden af coveret for at gøre det magnetisk.
4. Tænd powerbanken på knappen og ret powerbanken mod den trådløse opladningsposition på mobiltelefonen for at oplade mobiltelefonen.
5. Fjern powerbanken fra mobiltelefonen for at stoppe opladningen.
6. Powerbanken slukker automatisk, hvis ikke den bliver benyttet.
7. Hvis det trådløse Qi-udstyr er langt væk fra midten af powerbanken, vil enheden ikke gå i opladningstilstand. Flyt enheden til midten af powerbanken, og opladningen vil automatisk starte.
8. Ved ladefejlfjern mobiltelefonen fra powerbanken og sæt den på powerbanken for at gå tilbage til opladningstilstand.

## Vigtigt

1. Powerbanken har overstrømsbeskyttelse (OCP), kortslutningsbeskyttelse, overspændings- og underspændingsbeskyttelse (UVP), fremmedlegemer (FOD), dvalebeskyttelse og andre funktioner.
2. Undgå direkte sollys, høje temperaturer, og hold enheden væk fra ild og andre varmekilder.
3. Opbevares i et tørt miljø og undgå ætsende stoffer.
4. Powerbanken skal holdes på 50% af den nominelle kapacitet, hvis den ikke benyttes i mere end 3 måneder.
5. For at forhindre eksplosion, undgå at udsætte powerbanken for ild. Må ikke skilles ad.

Sinox Europe A/S  
Troensevej 11. DK-9220 Aalborg