

SINOX®


SXI0840 Manual

3 in 1 Fast Wireless Charger



Note: To ensure charging 3 devices safely and efficiently, you must use 9V/2.7A adapter and quick charge cable, (if not use the appropriate adapter and quick charge cable, the charger may not charge phone, or may not charge 3 devices simultaneously or may even damage the charger).

Product Appearance




Product Introduction

The 3-in-1 wireless charger, a compact charging house, powered from only one outlet, can charge 3 devices simultaneously. When charge your mobile phone, apple watches, and your AirPods 2 or AirPods Pro or some other TWS, just put them on, wireless charging will automatically start, all this will make your desk clean and tidy, and make your life easier. The charger is so space-saving designed can help you integrate your mobile phone intelligent and life very well, especially for Apple user. Besides, it is fashion that the light ring is so shining showing the charging state.

Operation Steps

1. Connect the charger to a 9V/2.7A adapter through a type-C quick charge cable to switch on the power.
2. Put your phone on then charge.
3. Put the apple watch on and suck it up to charge.
4. Put your earphone case on and charge.



LED light instructions

- **Power on:** Flashing once
- **Charge:** The running light lasts for 60 seconds, then off.
- **Full:** The green light is steady on.
- **Standby:** The white indicator is on for 30 seconds and the indicator is off.
- **Foreign body:** The red light is blinking.

Applicable Devices

1. **Smartphones**
All smartphones with wireless charging functionality, including Apple iPhone, Samsung Galaxy, LG, Motorola, Huawei, Xiaomi, and more.
2. **Smartwatches**
Apple iWatch
3. **TWS Bluetooth Earphones**
All TWS with wireless charging functionality, including Apple AirPods, Samsung, Huawei, and more.

Product Specification

- **Input:** 9V/2A, 9V2.7A
- **Phone Output:** 15W / 10W / 7.5W / 5W
- **Watch Output:** 2.5W
- **Earphone Output:** 3W
- **Input interface:** Type-C™
- **Transmission Distance(Phone):** ≤8mm
- **Conversion Rate(Phone):** ≥73%
- **Product Size:** 98.3 x 24.7 x 95.8mm

Accessories List

- Wireless Charger* 1
- Type-C™ quick charge cable* 1
- User manual*1

Attention

1. Please keep the charger away from water or other liquid.
2. If you need to clean the charger, please make sure it is not connected power supply.
3. Using Environment temperature remains 0 - 45°C.
4. Charging environment of smart phone will not be <55°C (<131°F).

Answer questions

If you're experiencing interrupted or slow charging, check the following:

1. The back of your phone should not have any metal, pop sockets, or credit cards.
2. Put the phone in the center of the charging surface (this lets the charging coil in your phone line up with the one inside the wireless charger).
3. The wireless charging coil on Sony phones is located slightly below center.
4. Phone cases should be no thicker than 5mm for effective charging.
5. Check whether the adapter is QC3.0 fast charger.

If you're failing to charge your device, please try out the following:

1. Please restart your cell phone and test with other USB cable.
2. Please check whether the indicator turns on or not.
3. Please check the Adapter is Quick Charger (Output:9V/2.7A) or not, iPhone original adapter does not match the wireless charger.
4. Please check your Phone case thickness(<5mm). Metal ring or Magnetic Pad will not be available.

If you're using the recommended wireless charger with the 9V/2.7A adapter and haveremoved any potential charging obstructions, but are still experiencing issues.

Try:

1. Replacing the cable connecting your the wireless charger.
2. Rebooting your phone.
3. Unplug the adapter and reinsert.

Sinox Europe A/S
Troensevej 11. DK-9220 Aalborg

SINOX®


SXI0840 Manuel

3-i-1 Hurtig Trådløs Oplader



Bemærk: For at sikre sikker og effektiv opladning af 3 enheder samtidig, skal du bruge en 9V/2.7A adapter og et quick charge-kabel. (Hvis du ikke bruger den korrekte adapter og kabel, kan opladeren muligvis ikke oplade telefonen, ikke oplade 3 enheder samtidigt eller endda tage skade).

Produktets Udseende




Produktintroduktion

Denne 3-i-1 trådløse oplader er en kompakt opladningsstation, der kun kræver ét strømstik og kan oplade 3 enheder samtidigt. Når du oplader din mobiltelefon, dit Apple Watch og dine AirPods 2, AirPods Pro eller andre TWS-enheder, skal du blot placere dem på opladeren – den trådløse opladning starter automatisk. Det holder dit skrivebord ryddeligt og gør hverdagen nemmere. Designet er pladsbesparende og integrerer nemt din smartphone i din hverdag – især for Apple-brugere. Desuden giver den lysende ring et moderne udtryk og viser opladningsstatus.

Trin for brug

1. Tilslut opladeren til en 9V/2.7A adapter med et Type-C quick charge-kabel for at tænde for strømmen.
2. Læg din telefon på opladeren for at begynde opladning.
3. Læg dit Apple Watch på opladeren – det fastgøres magnetisk og oplades.
4. Læg dit earbud-etui på opladeren for at oplade.



LED-lysindikator

- **Tændt:** Blinker én gang.
- **Oplader:** LED båndet lyser i 60 sekunder, derefter slukker den.
- **Fuld opladet:** Grønt lys lyser konstant.
- **Standby:** Hvid indikator lyser i 30 sekunder, derefter slukker den.
- **Fremmedlegeme registreret:** Rødt lys blinker.

Kompatible Enheder

1. **Smartphones**
Alle smartphones med trådløs opladningsfunktion herunder Apple iPhone, Samsung Galaxy, LG, Motorola, Huawei, Xiaomi m.fl.
2. **Smartwatches**
Apple iWatch
3. **TWS Bluetooth-høretelefoner**
Alle TWS med trådløs opladningsfunktion herunder Apple AirPods, Samsung, Huawei m.fl.

Produktspecifikationer

- **Input:** 9V/2A, 9V2.7A
- **Telefonudgang:** 15W / 10W / 7.5W / 5W
- **Urudgang:** 2.5W
- **Høretelefonudgang:** 3W
- **Indgangsport:** Type-C™
- **Overførselsafstand (telefon):** ≤8mm
- **Effektivitet (telefon):** ≥73%
- **Produktmål:** 98.3 x 24.7 x 95.8mm

Medfølgende tilbehør

- Trådløs oplader* 1
- Type-C™ quick charge-kabel* 1
- Brugervejledning*1

Vigtigt

1. Hold opladeren væk fra vand og andre væsker.
2. Rengør ikke opladeren mens den er tilsluttet strøm.
3. Brug opladeren i omgivelser mellem 0 - 45°C.
4. Opladningstemperaturen for smartphones må ikke overstige 55°C (131°F).

Ofte stillede spørgsmål

Hvis opladningen er afbrudt eller langsom, tjek følgende:

1. Der må ikke være metalgenstande, pop-sockets eller kreditkort på bagsiden af telefonen.
2. Placér telefonen i midten af opladefladen (så ladekranen passer med opladningsspolen i telefonen).
3. På Sony-telefoner sidder den trådløse spole lidt under midten.
4. Brug ikke covers tykkere end 5mm.
5. Sørg for at adapteren er en QC3.0-hurtigoplader.

Hvis enheden slet ikke oplader:

1. Genstart din telefon og prøv med et andet USB-kabel.
2. Tjek om indikatorlyset tændes.
3. Tjek at adapteren er en Quick Charger med output 9V/2.7A – iPhones originale adapter virker ikke.
4. Tjek tykkelsen på dit cover (<5 mm). Metalringe og magnetplader forhindrer opladning.

Hvis du bruger den anbefalede oplader med 9V/2.7A adapter og har fjernet alle forhindringer, men stadig oplever problemer:

1. Prøv et andet kabel.
2. Genstart telefonen.
3. Tag adapteren ud og sæt den i igen.

Sinox Europe A/S
Troensevej 11. DK-9220 Aalborg