

# SXL3012 Manual: 135\*105\*35mm

**SXL3012**

**Sinox Europe A/S**  
Troensevej 11. DK-9220 Aalborg



**True Wireless Earphones User Manual**

## CAUTION

- When not in use for a long period of time please turn off the Earbuds and store carefully to avoid any damage.
- In order to prolong the battery life, please charge every 1 month when not in use for a long period of time.
- Please charge the Earphones first if they have been left unused for a long time.
- The batteries in the Earphones and Charging case are original and please do not attempt to change them yourself.
- Please keep the Earphones and Charge Case in a dry place.
- Please keep away from high heat sources to avoid battery blast accidents.
- Do not play at high volumes for long periods at a time to avoid potential hearing damage.
- Do not use the Earphones in a dangerous place or whilst driving.

## HOW TO WEAR

Please select the suitable Eartips for use, there are two extra sizes to select. Adjust to a comfortable fit.

## CHARGING

There is a built-in rechargeable battery inside both Earphones and the charging case, which must not be disassembled.

## POWER ON/OFF

- To Turn on the Earphones, take out the both earphones from the charging case, L & R earphone will pair with each other automatically. You will hear a "beep" sound. To turn off the earphones, place the earphones into the charging case.
- Another way to turn off the earphones: long press the touch button for a few seconds. You will hear a voice prompt confirming "Connected", means power off and paired successfully. To turn off the earphones off, long press the touch button for a few seconds. You will hear a voice prompt confirming "Power off".

## PHONE CALL

When receiving a phone call, short press the touch button to answer the call, and short press the touch button again to hang up. To reject an incoming call, press the touch button for 2 seconds.

## MUSIC & VOLUME

To play/pause music, double press the Right/Left touch button.  
To play next song, press Right touch button for 2 seconds.  
To play previous song, press Left touch button for 2 seconds.  
To turn Volume up, press once on the Right touch button.  
To turn Volume down, press once on the Left touch button.

**1**

Please Note: In working mode, if you turn off one Earphone, another one will be power off the also.

## PRODUCT OVERVIEW

### PACKAGE CONTENTS:

- Earphones \*1 pair
- USB Cable \*1pc
- Small & Medium Ear Caps \*2 pair
- Charging Case\*1pc
- User Manual

## CHARGING THE CASE

- To charge the case, plug the USB charging cable supplied into the charging port.
- Connect it to DC5.0V USB port or a suitable USB charging device.
- The RED led light flashes while charging.
- The LED light remain RED when charging completed

## CHARGING THE EARPHONES

- Place the earphones into the charging case.
- The led light remain RED on both Earphones indicating that they are charging.
- The RED light will switch off when the Earphones are fully charged, the charging case will also stop charging automatically.
- To alert you to the fact that your Earphones require charging you will hear a voice prompt indicating "please charge"
- Please note the earbuds will be off automatically when in the charging case.

## HOW TO REMOVE THE EARPHONE FROM THE CHARGING CASE

- Open the charging case's cover to about 90 degrees.
- Then remove both Earphones vertically.

## HOW TO PAIR

- Remove both Earphones from the case.
- The Earphones will pair with each other automatically.
- Providing your device/phone is switched on and within pairing distance your earphones will auto connect to your device the next time you switch them on.
- Turn on Bluetooth on your Bluetooth enabled device/phone and scan for "Q12", select and pair with the Earphones.
- Enjoy your music wirelessly in Stereo!

**2**

## SINGLE EARPHONE USE

- Remove one of the Earphones from the charging case.
- The earphone will enter pairing mode automatically. The red and blue lights flash alternately to confirm you are in pairing mode.
- Turn on Bluetooth on your Bluetooth enabled device and look for "Q12" and pair.
- When in Single mode the volume is controlled via your Bluetooth device/phone.
- Enjoy your music wirelessly!

## SPECIFICATIONS (earphones)

Bluetooth version 5.0  
Bluetooth profiles: A2DP, AVRCP, HFP, HSP  
Wireless range: 10M (open area)  
Battery: 40mAh x 2  
Music playing time up to 3-4 hours (1 charge)  
Standby time: 100 hours  
Speaker sensitivity: 105-13dB  
LED battery indicator

## SPECIFICATIONS (charging case)

Box recharge capacity: 300mAh  
Charging time for case: 1.5 hours  
LED battery charging indicator

## FEATURES

Bluetooth connectivity  
True Wireless Stereo (TWS)  
Touch buttons  
Up to 4 hours music playback - and up to an additional 8 hours using the charging case  
Music play/pause  
Volume & track control  
Clear sound with powerful bass  
Comfortable fit  
Ergonomic design  
Rechargeable battery  
Built-in mic for hands-free calls  
Answer/Reject incoming calls  
Micro-USB charging cable (included)  
Portable intelligent charging case (included)  
Extra ear buds (included)

**3**

**SXL3012**

**Sinox Europe A/S**  
Troensevej 11. DK-9220 Aalborg



**Ægte trådløse øretelefoner brugervejledning**

## ADVARSEL

- Sluk ørepropperne og opbevar dem forsigtigt, hvis de ikke bruges i lang tid, for at undgå skader.
- For at forlænge batteriets levetid bedes du oplade en gang om måneden, når de ikke bruges i lang tid.
- Oplad først øretelefonerne, hvis de har været brugte i lang tid.
- Batterierne i øretelefonerne og opladningsetuiet er originale - prøv ikke at skifte dem selv.
- Opbevar øretelefoner og opladningsetui i tørt sted.
- Holdes væk fra høje varmekilder for at undgå batterisprængningsulykker.
- Spil ikke ved høje lydstyrker i lange perioder ad gangen for at undgå potentiel høreskade.
- Brug ikke øretelefonerne et farligt sted eller under kørsel.

## TILPASNING

Vælg de ørestykker der passer dig bedst, der er to ekstra størrelser at vælge mellem. Juster til en behagelig pasform.

## OPLADER

Der er et indbygget genopladeligt batteri inde i både øretelefoner og opladningsetui, som ikke må skilles ad.

## TÆND/SLUK

- For at tænde øretelefonerne skal du tage begge øretelefoner ud af opladningsetuiet, L & R-øretelefon parres automatisk med hinanden. Du vil høre en "bip"-lyd. For at slukke for øretelefonerne, anbring øretelefonerne i opladningsetuiet.
- En anden måde at tænde/slukke for øretelefonerne: Tryk på berøringsknappen i et par sekunder. Du vil høre en stemmemeddelelse, der bekræfter "Connected", betyder parret med succes. For at slukke øretelefonerne, tryk på berøringsknappen i et par sekunder. Du vil høre en stemmemeddelelse, der bekræfter "Power off".

## TELEFONOPKALD

Når du modtager et telefonopkald, skal du trykke kortvarigt på berøringsknappen for at besvare opkaldet og trykke kortvarigt igen på knappen for at lægge på. For at afvise et indgående opkald skal du trykke på berøringsknappen i 2 sekunder.

## MUSIK & LYDSTYRKE

For at afspille/pause musik, skal du dobbeltklikke på højre/venstre berøringsknapp.  
For at afspille den næste sang skal du trykke på den højre berøringsknapp i 2 sekunder.  
For at afspille den forrige sang skal du trykke på den venstre berøringsknapp i 2 sekunder.  
For at skruer op for lydstyrken skal du trykke én gang på højre berøringsknapp.  
For at skruer ned for lydstyrken skal du trykke én gang på den venstre berøringsknapp.

**1**

Bemærk: Hvis du slukker for den ene øretelefon, vil den anden slukke automatisk.

## PRODUKT OVERSIGT

### PAKKEINDHOLD

- Øretelefoner \* 1 par
- USB-kabel \* 1 stk
- Små og mellemstore ørehætter \* 2 par
- Opladningsetui \* 1 stk
- Brugervejledning

## OPLADNING AF ETUI

- For at oplade etuiet skal du sætte det medfølgende USB-opladerkabel i opladningsporten.
- Tilslut den til DC5.0V USB-port eller en passende USB-opladningsenhed.
- Det RØDE LED-lys blinker under opladning.
- LED-lampen forbliver RØD, når opladningen er afsluttet.

## OPLADNING AF ØRETELEFONERNE

- Anbring øretelefonerne i opladningsetuiet.
- LED-lampen forbliver RØD på begge øretelefoner, hvilket indikerer, at de oplades.
- Den RØDE lampe slukkes, når øretelefonerne er fuldt opladet. Opladningsetuiet vil også tænde opladningen automatisk.
- For at advare dig om, at dine øretelefoner kræver opladning, hører du en stemmemeddelelse "angiver "please charge".
- Bemærk, at ørepropperne automatisk slukkes, når de er i opladningsetuiet.

## SÅDAN FJERNES ØRETELEFONEN FRA OPLADNINGSETUIET

- Åbn dækslet til opladningsetuiet til ca. 90 grader.
- Fjern derefter begge øretelefoner lodret.

## SÅDAN PARRER DU

- Fjern begge øretelefoner fra etuiet.
- Øretelefonerne parres automatisk med hinanden.
- Forudsat at din enhed/telefon er tændt, og inden for parningsafstand, vil dine øretelefoner automatisk oprette forbindelse til din enhed, næste gang du tænder dem.
- Tænd Bluetooth på din Bluetooth-aktiverede enhed/telefon, og søg efter "SXL3012", vælg og par med øretelefonerne.
- Nyd din musik trådløst i stereo!

**2**

## ANVENDELSE AF ENKEL ØRETELEFON

- Fjern en af øretelefonerne fra opladningsetuiet.
- Øretelefonen skifter automatisk til parningsstand. De røde og blå lys blinker skiftevis for at bekræfte, at du er i parningsstand.
- Tænd Bluetooth på din Bluetooth-aktiverede enhed, og se efter "SXL3012" og par.
- Når du er i enkelt tilstand, styres lydstyrken via din Bluetooth-enhed/telefon.
- Nyd din musik trådløst!

## SPECIFIKATIONER (øretelefoner)

Bluetooth version 5.0  
Bluetooth-profiler: A2DP, AVRCP, HFP, HSP  
Trådløs rækkevidde: 10m (åbent område)  
Batteri: 40mAh x 2  
Musik spilletid op til 3-4 timer (1 opladning)  
Standby tid: 100 timer  
Højttalerfølsomhed: 105 ± 3dB  
LED-batterindikator

## SPECIFIKATIONER (opladningsetui)

Boksens genopladningskapacitet: 300mAh  
Opladningstid for etui: 1,5 time  
LED-batteriopladningsindikator

## FUNKTIONER

Bluetooth-forbindelse  
Ægte trådløs stereo (TWS)  
Touch-knapper  
Op til 4 timers musikafspilning - og op til yderligere 8 timer ved hjælp af opladningsetuiet  
Musikafspil/pause  
Styring af lydstyrke og spor  
Klar lyd med kraftig bas  
Behagelig pasform  
Ergonomisk design  
Genopladeligt batteri  
Indbygget mikrofon til håndfri opkald  
Besvar/afvis indgående opkald  
Micro-USB-opladerkabel (inkluderet)  
Berbar intelligent opladningsetui (inkluderet)  
Ekstra ørepropper (inkluderet)

**3**